G2ZIF20 24-240V



Timers - Multifunction

GAMMA series

7 functions

10 time ranges

Connection of remote potentiometer possible

Zoom voltage 24 to 240V AC/DC

2 change-over contacts

Width 22.5mm

Industrial design



Technical data

1. Functions

Asymmetric flasher pause first lp

Asymmetric flasher pulse first
ON delay and OFF delay with control input ER

FWu ON delay and single shot leading edge voltage controlled ON delay single shot leading edge with control input **EWs** WsWa Single shot leading and single shot trailling edge

with control contact Wt Pulse detection

2. Time ranges

2. Time ranges		
Time range	Adjustment range	
1s	50ms	1s
3s	150ms	3s
10s	500ms	10s
30s	1500ms	30s
1min	3s	1min
3min	9s	3min
10min	30s	10min
30min	90s	30min
1h	3min	1h
10h	30min	10h

3. Indicators

Green LED U/t1 ON: indication of supply voltage Green LED U/t1 flashes: indication of time period t1 Green LED t2 flashes: indication of time period t2 Yellow LED ON/OFF: indication of relay output

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-Rail TS 35 according to EN 60715 Mounting position: any

Shockproof terminal connection according to VBG 4

(PZ1 required), IP rating IP20 Tightening torque: max. 1Nm

Terminal capacity:

1 x 0.5 to 2.5mm² with/without multicore cable end

1 x 4mm² without multicore cable end

2 x 0.5 to 1.5mm² with/without multicore cable end $2 \times 2.5 \text{mm}^2$ flexible without multicore cable end

5. Input circuit

Supply voltage:

24 to 240V AC/DC terminals A1-A2 (galvanically separated)

Tolerance:

24 to 240V DC -20% to +25% 24 to 240V AC -15% to +10% Rated frequency: 24 to 240V AC 48 to 400Hz 16 to 48Hz

48 to 240V AC 4.5VA (1W) Rated consumption: Duration of operation: 100% Reset time: 500ms Wave form for AC: Sinus Residual ripple for DC: 10%

Drop-out voltage: >15% of the supply voltage Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage:

6. Output circuit

2 potential free change over contacts Rated voltage: 250V AC

750VA (3A / 250V AC) Switching capacity: If the distance between the devices is less than 5mm! Switching capacity: 1250VA (5A / 250V AC) If the distance between the devices is greater than 5mm!

Fusing: 5A fast acting Mechanical life: 20 x 10⁶ operations

Electrical Life: 2 x 10⁵ operations at 1000VA resistive load max. 60/min at 100VA resistive load Switching frequency: max. 6/min at 1000VA resistive load (in accordance with IEC 60947-5-1)

Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage:

7. Control contact

bridge Y1-Y2 Activation:

Potential free: yes, basic isolation against input and

output circuit

Loadable: no

max. 5V Control voltage: Short circuit current: max. 1mA Line length: max. 10m

Control pulse length: min. 50ms (except Wt function)

min. 7ms (Wt function only)

8. Remote potentiometer (not included)

The internal potentiometer is de-activated when a remote potentio-meter

is connected !!!

 $1M\Omega$ potentiometer (type RONDO R2), Connections: terminals Y2-Z1 resp. Y2-Z2

twisted pair Line type: Control voltage: max. 5V Short circuit current: max. 5uA Line length: max. 5m

9. Accuracy

±1% (of maximum scale value) Base accuracy:

using $1M\Omega$ remote potentiometer

Frequency response:

Adjustment accuracy: ≤5% (of maximum scale value)

using $1M\Omega$ remote potentiometer

Repetition accuracy: <0.5% or ±5ms

Technical data

10. Ambient conditions

Ambient temperature: -25 to +55°C

(in accordance with IEC 60068-1)

-25 to +40°C

(in accordance with UL 508)

Storage temperature: -25 to +70°C
Transport temperature: -25 to +70°C
Relative humidity: -25 to +70°C
15% to 85%

(in accordance with IEC 60721-3-3class 3K3)

Pollution degree: 3 (in accordance with IEC 60664-1)

Vibration resistance: 10 to 55Hz 0.35mm

(in accordance with IEC 60068-2-6)


Shock resistance: 15g 11ms (in acordance with IEC 60068-2-27)

Functions

The internal potentiometer is de-activated when a remote-potentio-meter is connected! The function has to be set before connecting the relay to the supply voltage.


Asymmetric flasher pause first (lp)

When the supply voltage U is applied, the set interval t1 begins (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 fluminated), the output relay R switches into on-position (yellow LED illuminated) and the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated), the output relay switches into off-position (yellow LED not illuminated). The output relay is triggered at the ratio of t1:t2 until the supply voltage is interrupted.




Asymmetric flasher pulse first (li)

When the supply voltage U is applied, the output relay R switches into on-position (yellow LED illuminated) and the set interval t1 begins (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 illuminated), the output relay switches into off-position (yellow LED not illuminated) and the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated), the output relay switches into on-position (yellow LED illuminated). The output relay is triggered at the ratio of t1:t2 until the supply voltage is interrupted.




ON delay and OFF delay with control contact (ER)

The supply voltage U must be constantly applied to the device (green LED U/t1 illuminated). When the control contact S is closed, the set interval t1 begins (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 illuminated), the output relay R switches into on-position (yellow LED illuminated). If the control contact is opened, the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated) the output relay switches into off-position (yellow LED not illuminated). If the control contact is opened before the interval t1 has expired, the interval already expired is erased and is restarted with the next cycle.




ON delay and single shot leading edge voltage controlled (EWu)

When the supply voltage U is applied, the set interval t1 begins (gree LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 illuminated), the output relay R switches into on-position (yellow LED illuminated) and the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated), the output relay switches into off-position (yellow LED not illuminated). If the supply voltage is interrupted before the interval t1+t2 has expired, the interval already expired is erased and is restarted when the supply voltage is next applied.



ON delay and single shot leading edge with control contact (EWs)

The supply voltage U must be constantly applied to the device (green LED U/t1 illuminated). When the control contact S is closed, the set interval t1 begins (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 illuminated), the output relay R switches into on-position (yellow LED illuminated) and the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated) the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times. A further cycle can only be started when the cycle run has been completed.




Functions

Single shot leading and single shot trailing edge with control contact (WsWa)


The supply voltage U must be constantly applied to the device (green LED U/t1 illuminated). When the control contact S is closed, the output relay R switches into on-position (yellow LED illuminated) and the set interval t1 begins (green LED U/t1 flashes). After the interval t1 has expired (green LED U/t1 illuminated), the output relay R switches into off-position (yellow LED not illuminated).

If the control contact is opened, the output relay again switches into on-position (yellow LED illuminated) and the set interval t2 begins (green LED t2 flashes). After the interval t2 has expired (green LED t2 not illuminated) the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times.




Pulse sequence monitoring (Wt)

When the supply voltage U is applied, the set interval t1 begins (green LED U/t1 flashes) and the output relay R1 (15-16-18) switches into on-position (yellow LED illuminated). After the interval t1 has expired (green LED U/t1 illuminated), the set interval t2 begins (green LED t2 flashes). So that the output relay R1 remains in on-position, the control contact must be closed and opened again within the set interval t2. If this does not happen, the output relay R1 switches into off-position (yellow LED not illuminated) and the output relay R2 (25-26-28) switches into on-position. All further pulses at the control contact are ignored. To restart the function the supply voltage must be interrupted and re-applied.



Connections



Dimensions

